

F/R: Connects GND = CW running, Disconnect = CCW running
 EN: Connects GND = Stop, Disconnect = Run
 SV: 0-5V or PWM
 FG: Motor Speed Pulse

2. **Operate Voltage: 15-30VDC.** "+" and "-" poles cannot be reversed
3. **Continuous Current: 8A, Peak Current: 16A**
4. **Power Supplier Output Current > Rated Motor Current**
5. **Error Code**

6. Motor Starting Time: 2s
7. Total Weight: 135g

